(BK) GPH, GPH Plus, DPH



(BK) Changing Groups: Press #, the group number, ENT

(BK) Adding/Deleting Scan List Channels (scan/pri must be off)

"ENT" to add channel to Scan

"CLR" to delete channel to Scan List

<u>Turn Scan on/off</u>

Toggle SCN and PRI on (turn both on at the same time)

(BK) KEYPAD LOCKS:

When SCAN and PRI are on, keypad is locked Pressing FCN locks the keypad on some radios

(BK) CG-SQ Knob

Turning this CCW until clicks tone (password) protects the radio – do not use in this position. Rotate knob until static is heard and then back if off slightly.

Tone Select

AUX C (select

command

channels)

group

Up/Down

(BK) GPH CMD



GPH, GPH+, DPH

TONE Select (SCN and PRI must be off). Press the number corresponding to the required tone.

IMPORTANT (GPH, GPH+, DPH):

The tone must be selected EACH time a channel is changed (for channels that require a tone).



GPH-CMD, Kenwood

TONE Select (SCN and PRI must be off). Press the number corresponding to the required tone.

IMPORTANT (GPH-CMD and Kenwood)

You can only select tones on channels that have more than one tone – channels with single tone access are locked.



HC

CDF CMD 1

VOL. CH.

HC - Home Channel

TA - Talk Around

SCN

QL AUX C

SQL – Squelch

Adjust w/ CH knob


GPH-CMD, Kenwood COMMAND GROUP

The GPH-CMD and Kenwood can build a command group. GPH-CMD

* to add chan. to cmd group ## to go to cmd group When in cmd grp, * to delete

Kenwood

AUX C add/del fm cmd group Group up/down to cmd group



To change Groups or Tones select from drop down menu then press OK or Enter

When adding Channels to CMD Group will default to CMD Group 1

You will need to assign a channel #, defaults to 1

Get to CMD Group by using the "Zone" button, (Group 26)

Once in CMD Group you need to build a Scan List for that group

Use the MENU button and associated drop down menus to

- Create a Scan List
- Enable or Disable Monitor Mode
 - Adjust Squelch
 - Enable Talk Around