

TITLE OPERATIONS MANUAL		STANDARD INSTRUCTION 11		DEPARTMENT FIRE
SUBJECT FIRE-RESCUE FLEET PROCEDURES: PURPOSE AND SCOPE		SECTION 01	PAGE 1 of 1	EFFECTIVE DATE 07/01/01

I. PURPOSE AND SCOPE

A. Purpose

The purpose of this Standard Instruction is to provide procedures, guidelines and criteria that shall be used by this department when removing an apparatus from service due to a mechanical failure, accident damage, or any safety related items.

B. Scope

These Instructions are designed to provide criteria for Company Officers and Repair Facility personnel to reference in determining whether a first-line fire apparatus should remain in service or be removed from service. Many of the items will also apply to non-Operations vehicles, i.e., staff, FHP, Training vehicles, etc. Any clarification of these procedures will be directed through the proper chain of command.